


# Optimum M4100




## Stylus Installation




1 Remove the stylus from the packaging.



2 Insert the stylus into the stylus holder (as shown).



3 Insert the stylus (as shown).



4 To use, remove the stylus from its holder and press gently on the terminal screen. When not in use, return the stylus to its holder.

World Headquarters:  
Hypercom Corporation | 2851 West Kathleen Road, Phoenix, Arizona 85053, USA  
Tel: +1.602.504.5000 | Fax: +1.602.504.4655 | www.hypercom.com  
© 2007, Hypercom Corporation. All rights reserved. 940513-006 Rev. A 04/07

