

Optimum M4100



Terminal Battery Installation

WARNING: When performing any maintenance on Hypercom products, ensure that you are grounded with an ESD strap in an anti-static environment. The battery pack is a Li-Ion polymer battery which can explode if not properly replaced, handled or disposed of in a proper manner. Dispose old batteries in accordance with local regulations. Use only batteries recommended by Hypercom as a replacement. For more information about Hypercom batteries, refer to the *Hypercom Battery Tips Guide* on www.hypercom.com/library.

Note: The terminal must be stored with a fully charged battery. If the terminal battery loses its charge due to a long storage time or stored without a battery, the terminal may not work properly.




1 Remove the battery from the packaging. Flip the terminal over (as shown).



2 Remove the battery cover from the terminal (as shown). To remove the old battery, grasp the battery ledge and lift from the terminal. Dispose of old battery properly according to local regulations.



3 Insert the new battery (as shown).



4 Reattach the battery cover. Turn the terminal on.

World Headquarters:
Hypercom Corporation | 2851 West Kathleen Road, Phoenix, Arizona 85053, USA
Tel: +1.602.504.5000 | Fax: +1.602.504.4655 | www.hypercom.com
© 2007, Hypercom Corporation. All rights reserved. 940513-004 Rev. A 04/07



NORTH AMERICA | CENTRAL AMERICA | LATIN AMERICA | ASIA/PACIFIC RIM | EUROPE | MIDDLE EAST | AFRICA